

Quick Start Guide - Under-Desk Basket Cable Tray

1. **Warning: Safety Gloves must be worn when mounting this product.**
2. **There may be extra connectors in the package.**

Step 1.

Depending on the length, you may need to connect 2 or more tray sections together using the connectors provided in the package, shown in the image left.



Step 2.

Add the plastic mounting brackets to the tray. They must be mounted always on one of the joints (where the horizontal and vertical wires meet). First slide it down then along the back, then pull up, shown in the image left.



Step 3.

Add the end plastic caps. Please push firmly till they click in position.

Step 4.

Mount the cables plastic cover. The cable tray is now assembled and ready to be mounted under desk.



Step 5.

Using the assembled cable tray to mark the mounting points under desk or front panel, two points for each mounting brackets, drilling a small pilot hole ($\varnothing 2$ to 3 mm) for each point.

Notes: There are 6 mounting holes in the mounting bracket, 4 facing up and 2 facing back. You can use any 2 of them to mount the bracket whichever are more convenient in your situation, and only 2 screws are provided for each bracket.